

# Sealant and Adhesive Remover



## removes residues of hardened gaskets

Sealant and Adhesive Remover quickly and easily removes residues of hardened sealants and adhesives as well as lacquers and paints, even from vertical surfaces.

Sealant and Adhesive Remover can be used on metal, wood, glass, ceramics, polyethylene and polypropylene. It should not be used on sensitive plastics such as PVC, synthetics, linoleum, etc.

Sealant and Adhesive Remover loosens all kinds of sealant residues on cylinder heads, oil sumps, water pumps, exhaust manifolds, valve covers and gearbox flanges. It reliably removes oil carbon residues, paints and lacquers, and eliminates oils, resins, greases and tar. It can also be used as a paint stripper for wood restoration and removes all kinds of adhesives, even cured cyanoacrylate and anaerobic adhesives.

## Technical Data

Odour	solvent
Features	powerful
Storage stability	12 months
Colour	pink

## Processing

Spray in sufficient quantity onto the part to be treated and allow to react. If necessary, wipe off with a clean cloth. Repeat process as required. Avoid contact with plastic and varnished surfaces.

## Storage

Pressurized container: protect from sunlight and do not expose to temperatures exceeding +50°C.

## Safety and health

When using products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets must be observed.

## Technotopogs FZCO

Head Office Middle East: Hamriya Free Zone-Sharjah, UAE  
Tel: +971 6 5262004 • Fax: +971 6 5262030  
info@technotopogs.com • www.technotopogs.com

Westhafenplatz 1  
60327 Frankfurt/Main, Germany  
Tel: +49 (0) 69 710456072